## 25442 2011 DODGE CHARGER



25442 2011 DODGE CHARGER

## **2011 DODGE CHARGER**

## **Billet Bumper Grille**

**TOOLS REQUIRED:** 

Screwdriver

**PARTS LIST:** 

(1) Billet Bumper

(2) 6/32 3" Machine Screws

(2) Spring Wing Clips

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

## Step 1

Insert a 6/32 1.5 Machine Screw through the brackets on the Billet Bumper Grille and thread a Spring Wing Clip on. (Thread many times so the Spring Wing wont get loose and fall off.) (Fig. 1) Place the Billet Grille over the Factory Bumper Grille and have the Spring Clips face Verticle, With semi-force, Push the Spring Clip through the Factory Bumper Grille. (Fig. 2) With a Screwdriver and holding the Billet Grille outward so the Spring Clip wont twist around, Start threading the Machine Screw. (Fig.3)

**Installation Complete** 







