



2014 JEEP GRAND CHEROKEE

Sport Series Grille

TOOLS REQUIRED:

Socket and Ratchet Set
Flat/Phillips Screwdrivers

- (16) #10 Washers
- (16) #8 Self Taping Screws
- (4) Christmas Tree Clips
- (1) Sport Series Grille



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquiries can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1

Factory Grille/Bumper Cover Removal

Remove 2 plastic pop clips from the radiator cover plastic with a flat head screwdriver (Fig 1 & 2). Remove the radiator cover. On the front edge of each front fenderwell are a plastic pop rivet, use a hammer and small phillips screwdriver or punch top knock the center of the plastic rivet inward (Fig 3). Remove the screw from the top of both fenderwells (Fig 4). Now pull the gray fender trim outward from from the fenderwell (Fig 5). Pull the top corners of the bumper cover outward there it meets the fender (Fig 6). From underneath the vehicle remove 5 plastic twist clips by hand from the splash guard (Fig 7). Pull the bumper cover forward about 6-12" (Fig 8). Reach behind the bumper cover and unplug both of the fog lamps (Fig 9). Remove the bumper cover. Continued on page 2.





Step 1 Continued

Factory Grille/Bumper Cover Removal

Remove the factory plastic grill inserts from the bumper cover using a flat head screwdriver to pop the plastic latches(Fig 10 & 11).



Step 2

Mesh Grille Installation

From the backside of the factory grille insert the sport series mesh grille into the factory grille (Fig 12). Make sure the mesh grille is seated into the factory grill. Now take the hardware that is included with the sport series grille, place a washer onto each self tapping screw and install two screws between each opening in the factory grill (Fig 13). The screws will screw into the plastic on the back side of the factory grill. This will hold the sport series grille into the factory grill. Reinstall the completed factory grill/ bumper cover in the reverse order from the removal. The plastic christmas tree clips will be used in the fenderwells where you knocked out the centers in Fig 3. Installation complete. Thank you for purchasing a T-REX Grille.

