

54433
54434

11-12

Chrysler 300C



54433
54434

11-12

Chrysler 300C

11-12 CHRYSLER 300C

Upper Class Mesh Grille

Install time: 30 Mins.

TOOLS REQUIRED:

Plastic Prybar
10mm & 7mm Socket Wrench
3/16 Drillbit & Drill
Screwdriver

PARTS LIST:

(1) Mesh Grille
(4) #8 Flat Nuts
(4) 6/32 Nylon Lock Nuts
(4) 3/4 #8 Screws
(4) 10/32 Fender Flatwashers

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

Step 1 Factory Grille Shell Removal

- Remove 8 clips on the Plastic Cover. (Fig. 1)
- Carefully pull on Grille Shell to remove part of the Plastic Cover. (Fig. 2)
- With a Plastic Prybar Unclip the Plastic Cover from the Factory Grille Shell. (Fig. 3)
- Remove Plastic Cover. (Pull Grille Shell Carefully outward if Plastic Cover doesnt come off.)
- Remove 2 clips on side Fender Well. (Fig. 4)
- Remove 10mm Bolt on the inner Fender. (Fig. 5)
- Pull Side Fender outward to Unclip. (Fig. 6)
- Remove 8 (7mm) Screws from Underneath the Factory Grille Shell. (Fig. 7)
- Remove Grille Shell and unclip the Electric Wire from the Fog Lights.

Step 2 Factory Grille Removal

- Remove 2 Clips on the Bumper Support. (Fig. 8)



