

55188

**06-11 CADILLAC
DTS**



55188

**06-11 CADILLAC
DTS**

2006-11 Cadillac DTS **UPPER CLASS SERIES MESH GRILLE**

Tools Required:

Phillips & Slotted Screw Drivers
7mm, 8mm & 10mm Socket

Parts List:

1	Upper Class Grille	8	Nylon Lock Nuts
8	½" X ½" L Brackets		

Read and understand instructions before attempting installation

Step 1

Locate your new grille. Make sure that all the hardware listed above is present. Place the new grille into the bumper opening. From the backside of the bumper; place an L bracket and nylon lock nut on each. Make sure that the L brackets wrap onto the factory bumper plastic. Make sure that the grille is centered and tighten all the hardware.



Thank you for purchasing a T-Rex billet grille. 04/11/08