

55195
07-12 CADILLAC
ESCALADE



55195
07-12 CADILLAC
ESCALADE

2007-12 Cadillac Escalade
UPPER CLASS SERIES MESH BUMPER – FLUSH MOUNT

Tools Required:

Phillips & Slotted Screw Drivers
7mm, 8mm, 10mm & 18mm Socket
Drill & 1/8" Bit
Jacks, Jack-stands or Ramps

Parts List:

2 Upper Class Grilles (Right & Left)
6 6-32 Nylon Lock Nuts
6 #6 Flat Washers
4 1/2 x 1/2 L Brackets
2 1.5" J Hooks

Read and understand instructions before attempting installation



Step 1

Access the tow hooks from below the bumper. It may be easier if the front of the vehicle is raised on jack stands or ramps. Use an 18mm socket and wrench to remove the factory tow hooks from the frame.

Step 3

Use a slotted screwdriver to unclip and remove the factory plastic tow hook covers.

Step 4

Center one on the grilles in place. Use the 1/2 x 1/2 brackets to secure the upper mounting studs. Attach the J hooks to the bottom studs. Install the washers and nuts. Make sure the brackets wrap around the bumper cover. Tighten the hardware until the grille is firmly held in place.

Thank you for purchasing a T-Rex billet grille. 5/31/07

