



## **2013 CADILLAC ATS**

### **Mesh Grille**

**Install time: 35 Mins.**

#### **TOOLS REQUIRED:**

3/16 Drillbit & Drill  
Screwdriver  
Socketwrench

#### **PARTS LIST:**

(2) Mesh Grille  
(4) 6/32 Nylon Lock Nuts  
(4) Fender Flatwashers  
(4) Christmas Tree Clips

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS  
BEFORE ATTEMPTING INSTALLATION.**

- Remove the License Plate and Remove the Splash Guard from the bottom of the Car to get to the Back of the Factory Bumper.
- Place the Mesh Grille onto the Bumper. (Fig. 1)
- From behind the Factory Bumper, Place Fender Flatwashers and Nylon Lock Nut onto the Thread Studs. (Fig. 2)

#### **OPTIONAL**

**if you want to put back the License Plate**

- Remove the Tabs on the License Place. (Fig. 3)
- Place back the License Plate and Put in the Christmas Tree Clips.

**INSTALLATION COMPLETE**

