



2013 CADILLAC ATS

Mesh Grille

Install time: 35 Mins.

TOOLS REQUIRED:

3/16 Drillbit & Drill
Screwdriver
Socketwrench

PARTS LIST:

(2) Mesh Grille
(4) 6/32 Nylon Lock Nuts
(4) Fender Flatwashers

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.**

- Remove the Splash Guard from the bottom of the Car to get to the Back of the Factory Bumper.
 - Place the Mesh Grille onto the Side of the Bumper. (Fig. 1)
 - Drill a 3/16 Hole through where the Studs on the Mesh Grille were. (Fig. 2)
 - From behind the Factory Bumper, Place Fender Flatwashers and Nylon Lock Nut onto the Thread Studs. (Fig. 3)
- Repeat for other Grille.

INSTALLATION COMPLETE

