

**55198**  
**08-12 CADILLAC**  
**CTS**



**55198**  
**08-12 CADILLAC**  
**CTS**

**08-12 Cadillac CTS**  
**BUMPER CAP INSERTS**

**Tools Required:**

Phillips & Slotted Screw Drivers  
8mm

**Parts List:**

2 Fog Light Inserts  
4 6-32 Nylon Lock Nuts  
4 #6 Flat Washers

**Read and understand instructions before attempting installation**

**Step 1**

Place the insert over the bumper cap inserts. While holding the insert in place; reach behind the bumper and bumper cap inserts and place a washer and nylon lock on each stud [1].



**Step 2**

Center the insert and tighten the nylon lock nuts. Repeat this process on the other side.

*Thank you for purchasing your T-Rex billet grille. 02/29/08*