

# **55193**

**03-07 CADILLAC  
CTS**



# **55193**

**03-07 CADILLAC  
CTS**

## **UPPER CLASS SERIES SIGNAL LIGHTS**

### **Tools Required:**

Philips Screwdriver  
7MM Sockets

### **Hardware:**

2 Upper Class Series (Right & Left)

## **Read and understand instructions before attempting installation**

### **Step 1**

Both grilles have a small tab with the hole; this tab points towards the front of the vehicle when installed. Match the grille with the correct signal light.

### **Step 2**

Remove the screw on top of the signal light opening. This screw retains the light. Do not move the signal light (if the light is moved out of place the fender well may need to be removed to re-install the light assembly).

### **Step 3**

Carefully center one of the grilles in place; slide the tabs on the bottom between the opening and the light. Push the top of the grille in place so the upper tab aligns to the factory hole. Re-install the factory mounting screw. ***Thank you for purchasing your T-Rex billet grille. 6/30/06***

