

21032/21032B
2014 CHEVROLET
CAMARO RS



21032/21032B
2014 CHEVROLET
CAMARO RS

2014 CHEVROLET CAMARO RS **Phantom Billet Grille**

TOOLS REQUIRED:

Socket and Ratchet Set
Flat/Phillips Screwdrivers

PARTS LIST

- (1) grille
- (4) #8 U-nuts
- (4) 2" Flange Brackets
- (4) #8 Six Head X 2" Screws



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Radiator Cover Removal & Grille Installation

Open the hood on the vehicle. Now remove the four 10mm bolts from the top of the radiator cover plate (Fig 1). Now remove six plastic pop clips that hold the radiator cover and the bumper cover together (Fig 2). Now remove the radiator cover plate (Fig 3) this will give you access to the rear of the factory grill. Install the four u-nuts onto the two flange brackets (Fig 4). Take the billet grille and insert it onto the factory grill (Fig 5). Take the four screws and insert them through the billet bars and the small square tabs with a hole in the center that are welded onto the back of the billet grille (Fig 6). Take the two flange brackets with the u-nuts installed and reach through the opening where the radiator cover was removed and locate the screws, take the flange brackets and install them onto the screws and tighten. Reinstall the radiator cover. Installation complete. Thank you for purchasing a T-REX Grille.



Fig 1



Fig 2



Fig 3



Fig 4



Fig 5



Fig 6