

52033

**2014 CHEVROLET
CAMARO SS**



52033

**2014 CHEVROLET
CAMARO SS**

2014 CHEVROLET CAMARO SS

Upper Class Bumper Grille

TOOLS REQUIRED:

Drill Bit Set and Drill Motor

PARTS LIST

- (1) Grille
- (4) Zip Ties
- (8) #8 U-Nuts
- (4) 55033 Support Bracket
- (8) SS Torx Screws 1.5"
- (1) 1/4" Torx Bit



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Grille Installation

Take the four Camaro support brackets and install the eight u-nuts onto them (Fig 1).



Step 2

Insert the brackets through the driver and passenger second and fourth vertical bumper bars (Fig 2). Make sure all bracket arms pointing outward and not to the center of the car. Use the four zip ties to secure the brackets to the backside of the vertical plastic bars in the factory bumper opening. With a 1/6" drill bit drill through the four upper u-nut center holes and the plastic and aluminum plate that is directly behind the u-nut (Fig 2 arrow).



52033

**2014 CHEVROLET
CAMARO SS**



52033

**2014 CHEVROLET
CAMARO SS**

Step 3 Grille Installation

With all the brackets installed on the bumper overlay your mesh grille into the factory bumper. Make sure the holes on the back of the mesh grille align with the u-nuts installed on the brackets. Insert the 1.5" screws through the hole in the mesh grille and the u-nuts and tighten. This will keep your grille secured and in place. Installation complete.

