

54026
51026
10-13 CHEVY
CAMARO SS



54026
51026
10-13 CHEVY
CAMARO SS

10-13 CHEVY CAMARO SS

Hood Scoop Trim

TOOLS REQUIRED:

Phillips Screwdriver

PARTS LIST

(2) #8 1" 6 Head Screw Polished

(1) Hood scoop Trim



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Install

Place the hood scoop trim into the hood scoop. Take the 2 supplied screws and insert them into the 2 holes on the outer edges of the hood scoop trim, use a phillips screwdriver to screw them into the factory hood scoop plastic. It might take a little bit of force to get the screws to penetrate the plastic. Installation complete.