

54168
08-12 CHEVY
MALIBU



54168
08-12 CHEVY
MALIBU

2 PC MESH GRILLE
2008-12 CHEVY MALIBU

Recommended Tools:

Philips/Slotted Screwdriver
8MM, 10MM Wrench or Nut Driver

Parts List / Hardware:

2 Mesh Inserts (Top and Bottom)
6 1/8" Fender Washers
6 6/32 Nylon Lock Nuts

Read and understand instructions before attempting installation

Step 1

Open the hood. Remove the plastic clips and 10mm bolts to remove the upper shroud to allow access to the back of the stock grill.



Step 2

Insert the lower grille insert. Place the grille studs through the factory grille backing. From the backside of the grille place a washer and nylon lock nut onto each stud (1). Tighten the screws till snug.

Step 3

Install the upper grille into the opening. Make sure the grille is centered. Place the grille studs through the factory grille backing. Using the provided washer and nylon lock nuts; secure the grille to the vehicle (1). Tighten the hardware till snug.

Step 4

Re-install the shroud to the vehicle and install the factory hardware.

Thank you for purchasing your T-Rex billet grille. 7/17/08