



2014 CHEVY SILVERADO 1500

Billet Series Grille

TOOLS REQUIRED:

Flat/Phillips Screw Drivers

PARTS LIST:

- (8) 2" 6 Head Screws
- (8) U-Nuts
- (8) Flange Brackets
- (1) 2 Pc. Billet Grille



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquiries can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1

Grille installation

Take the eight U-Nuts and install them onto the flange brackets (Fig 1). Insert the screws through the front of the billet grille and through the small black square tabs that are welded to the back side of the billet grilles. Install flange brackets on the end of the screws about 1/4" with the bent ends of the flange brackets facing toward the billet grille (Fig 2). Place the billet grille into the factory grille opening, use a flat screwdriver to turn the flange brackets so that it inserts fully through the factory grille honeycomb (Fig 3). With a flat screwdriver turn the flange brackets vertically so that they grab the side of the honeycomb grille, hold the flange brackets with the screwdriver to keep it from turning while you tighten the screws (Fig 4). Repeat on the second grille. Installation complete.

