



2014 CHEVY SILVERADO 1500
Sport Series Grille

TOOLS REQUIRED:

- Socket Set
- 10mm wrench
- Flat/Phillips Screw Drivers
- Drill and 3/16" Bit

PARTS LIST:

- (16) 1/2" L-Brackets
- (16) 6/32" Nylon Lock Nuts
- (16) 1.5" J-Hooks



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1

Factory Grille Removal

Remove 12 plastic pop clips from the top of the plastic radiator cover with a flat screwdriver. Remove the plastic radiator cover (Fig 2). Remove four 10mm bolts from along the top of the factory grille (Fig 3). Remove four 10mm bolts from the bottom of the factory grille, two are on the corners and two are in the center of the bottom of the factory grille (Fig 4). These can be accessed from underneath the vehicle or by reaching down through the top of the engine compartment. Remove two 6mm bolts from the forward section of each front fenderwell where the bumper meets the fender (Fig 5 & 6). Now pull up on each top corner of the factory grille while pulling slightly forward, this will release the top of the factory grille (Fig 7). Now grab the top plastic bumper cover at the fenderwell where it meets the bumper (this is where you removed the bolts from earlier) and pull the bumper cover outward until it un snaps (Fig 8). Now remove the factory grille (the top plastic bumper cover is connected to the factory grille and will be removed with it (Fig 9). Place the grille/top bumper cover on a workbench.



Fig 1



Fig 2



Fig 3



Fig 4



Fig 5



Fig 6



Fig 7



Fig 8



Fig 9

44117 2014 CHEVY SILVERADO 1500



44117 2014 CHEVY SILVERADO 1500

Step 1 Continued

Factory Grille Removal

With the factory grille on the workbench remove the black plastic factory grille intake seal from the back side of the factory grille by removing fourteen 7mm bolts (Fig 10 & 11).



Fig 10



Fig 11

Step 2

Grille Installation

Take the two sport grilles and insert them into the openings on the factory grille (Fig 12). Press the grilles firmly to seat them into the factory grille. Take a J-hook and insert it through the mesh grille near the edge, the hook end will latch onto the mesh grille (Fig 13). On the backside of the factory grille locate the threaded end of the j-hook and place a 1/2" L-Bracket and nylon lock nut on the threaded stud and tighten it, the L-Bracket should latch around the plastic edge on the factory grille (Fig 14). Repeat this with the remaining j-hooks, nylon lock nuts and L-brackets evenly spaced around both mesh grilles. Reinstall the plastic intake seal onto the completed grille. Reinstall the completed grille back onto the vehicle, don't forget to reinstall the hardware in the fenderwells. Reinstall the radiator cover. Installation complete.



Fig 12



Fig 13



Fig 14

Thank you for purchasing a T-REX Grille.