



**7721221**  
**Chevrolet Silverado**  
**2500/3500 HD**

**7721221-BR**  
**Chevrolet Silverado**  
**2500/3500 HD**

**Step 3**

Gently lift the top of grille assembly up while pulling back at the same time. Depress the four (4) release tabs located on the inside of the factory grille assembly with your flat head screwdriver. Firmly grasp the grille pulling away from the vehicle to remove it. (Fig 3)



**Step 4**

Remove the two 10mm bolts securing the plastic grille cover to the bumper. Insert the mounting bracket in its location (bracket tabs should be facing towards center of opening). Insert the two U Nuts into the mounting bracket as shown. Secure the brackets with the factory screws. (Fig 4)

If your vehicle does not have the factory mounting bolts use the supplied #10 U nuts over the mounting holes, install as stated above and secure with the included #10 screws and washers.



**Step 5**

Insert the grille into the bumper opening. Secure the grille to the bracket in place with the included washers and nylock nuts. (Fig 5)



**Step 6**

Your installation is now complete. Reattach the grille assembly back to the vehicle in reverse order of removal. Make sure you reattach all clips and screws. (Fig 6)

