

54007

**07-12 SILVERADO
1500 & HD**



54007

**07-12 SILVERADO
1500 & HD**

07-12 CHEVY SILVERADO 1500 & HD

Billet Side Vent 2 Pc.

TOOLS REQUIRED:

Alcohol/Clean Rag

PARTS LIST:

Billet Side Vent - 2 Pc.

Step 1

Clean the area where the Side Vent will be installed with alcohol and a clean rag. Test fit the vent. Remove the plastic backing on the adhesive on the back of the vent.

Step 2

Position the vent on the upper portion of the fender as in the picture below. Press on the vent to ensure the adhesive backing adheres to the vehicle body. Repeat on other side of vehicle. Installation is complete.

