

T-REX TRUCK PRODUCTS INC.

25100

03-06 CHEVY

SILVERADO

TOW HOOK

BUMPER INSERT

25100

03-06 CHEVY

SILVERADO

TOW HOOK

BUMPER INSERT

2003-2006 SILVERADO BUMPER TOW HOOK BILLET INSERTS; 2 PC. SET

Tools Required:

Phillips Screw Driver
Drill
1/8" Drill Bit

Hardware / Parts Included:

2 - Billet Grille Insert (10 bars)
6 - #8 x 3/4" Phillip Screws
6 - #8 Flat Nuts

Read and understand instructions before attempting installation

Step 1.

Remove the factory tow hooks. Identify the left and right bumper inserts. Test fit the billets into the openings.

Step 2.

Hold the billets in place and mark the bracket hole to the openings. Drill a 1/8" hole at each mark. Secure the billets using the screws and nuts provided. Make sure the billets are centered and tighten the fasteners.

Step 3.

Installation is now complete. *Thank you for purchasing a T-Rex Billet Grille.*