

11052

07-08 GM

TRUCKS & SUV's



Corona, California

www.trexbillet.com

11052

07-08 GM

TRUCKS & SUV's

07-08 GM Trucks & SUV's

Center Armrest Trim

TOOLS REQUIRED:

Alcohol/Clean Rag

PARTS LIST:

1 T1 Series Center Armrest Trim

Step 1

Clean the area where the Trim Plate will be installed with alcohol and a clean rag. Test fit the trim plate.

Step 2

Peel adhesive backing off of the T1 Series Center Armrest Trim. Position the T1 Series Center Armrest Trim on top of the factory center armrest as in the picture below. Push down on the Center Armrest Trim to ensure the adhesive sticks to the factory center armrest.

