

55477
07-12 DODGE
CALIBER



55477
07-12 DODGE
CALIBER

UPPER CLASS SERIES MESH BUMPER

Tools Required:

Phillips / Slotted Screwdrivers
7mm / 10mm / 12mm Sockets
Black Spray Paint (Optional)

Hardware / Parts List:

1 Upper Class Mesh Bumper (No Frame)
4 Metal Clips (20268)

Read and understand instructions before attempting installation

Step 1

Open the hood and remove the 10mm bolts securing the radiator cover. Unscrews the four Phillips screws along the top of the grille; remove the radiator cover. Remove the three 10mm bolts and four plastic retainers securing the lower engine shield. Both wheel well fenders have two 7mm bolts securing it to the bumper cover. Remove these bolts to gain access to the bumper cover to fender retainer bolt. This bolt points upward and must be removed.

Step 2

Pull the bumper cover assembly cover forward. It may be necessary to loosen the plastic guide securing the bumper cover to the fenders. Place the bumper cover face down. Un-clip the plastic bumper inserts from the bumper cover. Test fit the mesh grille in place. The grille has notches to clear the factory molded tabs in the center.



Step 3

Re-install the bumper assembly and engine covers onto the vehicle. ***Thank you for purchasing your T-Rex billet grille. 9/27/06***