

# 21442

2011 DODGE  
CHARGER



# 21442

2011 DODGE  
CHARGER

## 2011 DODGE CHARGER

### Billet Grille Overlay/Bolt on - 4 Pc.

**TOOLS REQUIRED:**

Screwdriver

**PARTS LIST:**

- (4) Billet Grilles
- (8) 6/32 1.5 Machine Screws
- (8) Spring Wing Clips

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

**Step 1**

Insert a 6/32 1.5 Machine Screw through the brackets on the Billet Grille and thread a Spring Wing Clip on. (Thread many times so the Spring Wing wont get loose and fall off.) (Fig. 1)

Place the Billet Grille over the Factory Grille and have the Spring Wings face horizontal. (Make sure the Billet Grille is on the right way.) With semi-force, Push the Spring Clip through the Factory Grille. (Fig. 2)

With a Screwdriver and holding the Billet Grille outward so the Spring Clip wont twist around, Start threading the Machine Screw. (Fig.3)

**Installation Complete**

