

25442B

2011 DODGE
CHARGER



25442B

2011 DODGE
CHARGER

2011 DODGE CHARGER

Billet Bumper Grille

TOOLS REQUIRED:

Screwdriver

PARTS LIST:

- (1) Billet Bumper
- (2) 6/32 3" Machine Screws
- (2) Spring Wing Clips

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

Step 1

Insert a 6/32 1.5 Machine Screw through the brackets on the Billet Bumper Grille and thread a Spring Wing Clip on. (Thread many times so the Spring Wing wont get loose and fall off.) (Fig. 1)

Place the Billet Grille over the Factory Bumper Grille and have the Spring Clips face Verticle, With semi-force, Push the Spring Clip through the Factory Bumper Grille. (Fig. 2)

With a Screwdriver and holding the Billet Grille outward so the Spring Clip wont twist around, Start threading the Machine Screw. (Fig.3)

Installation Complete

