

25474

**05-10 DODGE
CHARGER (ALL)**



25474

**05-10 DODGE
CHARGER (ALL)**

BUMPER BILLET - POLISHED

Tools Required:

Philips Screwdriver

Hardware:

- 4 Billet Insert (5 bars)
- 2 #8 x 1 Screws (#6 HEAD)
- 2 #8 U-Nuts
- 2 3/4" J Hooks

Read and understand instructions before attempting installation

Step 1

Test fit the bumper insert into the opening; remove the grille. Slide the u-nuts onto the J hooks. Install the screws into the tabs welded to the grille. Thread the J hooks onto the screws.

Step 2

Center the grill and wrap the J hooks around the plastic bars in the opening. Use a screwdriver to secure the hardware. Do not over-tighten the screws. *Thank you for purchasing your T-Rex billet grille.*

T-Rex Truck Products Inc. 8/7/06

