

## **08-11 FORD ECONOLINE VAN XLT**

### **6 Pc. Upper Class Main Grille**

**TOOLS REQUIRED:**

8mm Socket & Ratchet

**PARTS LIST**

(12) 1/2" L-Brackets  
(12) 6/32" Nylon Lock Nuts  
(1) Mesh Grille Kit 6 Pc.

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION.** Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at [tech@trexbillet.com](mailto:tech@trexbillet.com) to verify fitment or assist with tech questions. All other inquires can be directed to [info@trexbillet.com](mailto:info@trexbillet.com). In the event you do not have internet access please call 1-800-287-5900.

### **Step 1 Mesh Grille Installation**

Take the six mesh grilles and insert them into the appropriate openings in the factory grille (Fig 1). From the backside of the factory grille locate the threaded studs that are welded to the backside of the mesh grilles and place the twelve 1/2" L-Brackets over them. The L-Brackets will latch around the plastic edge of the factory grille, now install the twelve 6/32" nylon lock nuts onto the threaded studs and tighten with a 8mm socket (Fig 2). Installation complete.

