

25567

99-04 FORD
F250 / F350 and
EXCURSION
BUMPER BILLET

with
Factory Fog Lights



25567

99-04 FORD
F250 / F350 and
EXCURSION
BUMPER BILLET

with
Factory Fog Lights

Tools Required:

7/16" Wrench
Drill
1/4" Drill Bit

Hardware / Parts Included:

1 - Billet Bumper Insert (8 Bars)
2 - 1/4-20 x 3/4 Bolts
2 - 1/4-20 Nuts
2 - 1/4 Flat Washers
2 - 1/4 Lock Washers

Read and understand instructions before attempting installation

Step 1

Place the billet insert in the center with the brackets in the opening first. Then align the insert as it will mount in the opening. The bottom of the billet should be sitting on the plastic.

Step 2

The two brackets will sit on top from the rear of the bumper. Be sure the insert is correctly positioned and then drill a 1/4" hole at each bracket. Insert a screw in each hole and a flat clip from behind. Tighten both screws.

Step 3

Installation of the billet bumper insert is complete. *Thank you for purchasing your T-Rex billet grille.*