



25515 05-09 FORD MUSTANG LX Models

BUMPER INSERT - LX MODELS

Recommended Tools:

Phillips Screw Drivers 5/16 Wrench or Nut Driver

Parts List / Hardware:


- 1 Billet Insert (7 Bars)
- 4 6-32 x 1.5 Machine Screw
- 4 6-32 Nylock Nuts & #6 Flat Washers
- 2 1.5" J Hooks
- 2 2" Flange Brackets

Read and understand instructions before attempting installation


Step 1

Insert a 1.5" machine screw into the inner tabs on the insert. From the back of the insert, slide a J hook, washer and Nylock nut on screws (thread the nuts by hand).

Center Mounting Tabs



Outer Mounting Tabs



Step 2

Now center the billet over the bumper openings. Wrap the J hooks around the top of the center opening. Install the flange brackets with the remaining screws, nuts and washers on the outer tabs. The flange brackets hold the billet to the honeycomb area in the bumper cover opening. Use a Phillips screwdriver and 5/16 wrench to snug the hardware down until the billet is held firmly in place.

Thank you for purchasing your T-Rex billet grille. 3/8/05