



54386 07-12 GMC ACADIA

UPPER CLASS SERIES MESH INSERTS

Tools Required:

Slotted Screwdriver Philips Screwdriver 8mm Socket

Hardware / Parts List:

- 1 Upper Class Mesh Insert
- 5 #10 Washers
- 5 6/32 Nylon Nuts

Read and understand instructions before attempting installation

<u>Step 1</u>

Remove 6 plastic fasteners holding plastic shroud cover; then remove six factory screws on grill shell top. (1) Also remove the 2 plastic fasteners on grill shell. The grill shell should now be loose from core support. Using two objects, wedge the between the core support and grill shell to obtain access to grill backing.





Step 2

Locate your mesh grill insert and test fit. Holding the grill shell with one hand; put a provided washer and a nylon nut on upper corner studs. (2) Do not tighten. Install washers and nylon nuts to remaining studs. Reinstall all factory parts described in step 1.

Thank you for purchasing your T-Rex billet grille. 8/16/07