

21316
04-13 GMC
SAVANA VAN



21316
04-13 GMC
SAVANA VAN

04-13 GMC SAVANA VAN **Billet Grille Overlay w/ Logo Opening**

TOOLS REQUIRED:

8mm Socket and Ratchet
Flathead Screwdriver

PARTS LIST

(4) 1 1/2" Machine Screws
(4) 1/2" "L" Brackets
(4) 6/32 Nylon Lock Nuts
(1) Billet Grille

Step 1

Remove the radiator top cover. There are several plastic pop clips that you can pry up with a flathead screwdriver. Set the radiator top cover to the side.

Step 2

Take the billet grille and insert it into the opening in the factory grille shell. (Fig 1)

Step 3

Take the four 1 1/2" machine screws and insert them through the billet bars and the small square brackets with a hole in the center that are welded onto the backside of the billet grille (Fig 2). Install the four 1/2" L-Brackets and 6/32" nylon lock nuts on the screws and tighten with a 8mm socket (Fig 3). Reinstall the radiator cover. Installation complete.

