

21153
10-12 GMC
TERRAIN



21153
10-12 GMC
TERRAIN

10-12 GMC TERRAIN

Billet Grille Overlay/Bolt-On w/ Logo Opening 1 Pc.

TOOLS REQUIRED:

Torx bits
Socket and Ratchet Kit
Flathead/Phillips Screwdriver

PARTS LIST:

(4) U-Nuts
(4) 2" Flange Brackets
(4) #8 (6 Head) 1 1/4" Screws
(1) Billet Grille



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE

INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquiries can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Loosen Top Radiator Covers

Loosen the radiator top cover and side covers. There are several plastic pop clips that you can pry up with a flathead screwdriver and bolts that require removal. This will allow you to get your hand behind the factory grille to install the hardware.

Step 2 Billet Grille Installation

Install the U-Nuts onto the flange brackets (Fig 1). With the top radiator cover loose you can now install the billet grille. First place billet grille into the factory grille opening (Fig 2). Take the four 1 1/4" Screws and insert them through the billet bars and the tabs with holes in them that are welded to the backside of the billet (Fig 3). Reach behind the factory grille through the open area where the top radiator covers connect and place the four 2" Flange Brackets over the ends of the four screws on the backside of the billet grille (the tapered ends will face toward the front of the vehicle) (Fig 4). Replace the hardware on top radiator covers. Installation complete.

