

# 25179

01-06 GMC

Yukon Denali

02-06 Sierra C3

AIR DAM BILLET

With Out Tow Hooks



# 25179

01-06 GMC

Yukon Denali

02-06 Sierra C3

AIR DAM BILLET

With Out Tow Hooks

**Tools Required:**

Phillip Screw Driver

**Parts List:**

1 - Air Dam Insert (9 Bars)

4 - #8 x 3/4 Phillip Screws

4 - #8 Flat Nuts

**Read and understand instructions before attempting installation**

**Step 1.**

**THE FACTORY TOW HOOKS MUST BE REMOVED FROM THE VEHICLE FOR THIS BUMPER BILLET INSERT.** Remove the factory plastic insert if the vehicle has one.

**Step2**

Center the billet in the air dam opening. There is a hole in each tab welded to the back of the insert where they meet the air dam opening. Align the billet with the holes and fasten with a screw and clip at each bracket. Tighten the four screws.

**Step3**

Installation complete. *Thank you for purchasing your T-Rex billet grille.*