

**25729**  
**08-10 HONDA**  
**ACCORD**  
**BUMPER INSERT**



**25729**  
**08-10 HONDA**  
**ACCORD**  
**BUMPER INSERT**

**08-10 HONDA ACCORD**  
**BUMPER INSERT**

**Tools Required:**

Phillip Screw Driver

**Hardware / Parts Included:**

- 1 Billet Insert
- 2 1 1/4" #6 Screws
- 2 U Nuts
- 2 2" "J" Hooks

**Read and understand instructions before attempting installation**

**Step 1**

Center the grille insert into place. Place a machine screw in each mount on the billet insert. Install a U nut on each "J" hook. From the back side; place the screw into the u nut making sure that the J hook wraps around the factory plastic.



**Step 2**

Tighten the screws down with the "J" hooks catching the rear edge of the bumper cover. Do not over tighten.

*Thank you for purchasing a T-Rex Billet Grille. 1/04/08*