

55293

HUMMER

H3 SUV



55293

HUMMER

H3 SUV

06-09 HUMMER H3 SUV UPPER CLASS SERIES BUMPER

Recommended Tools:

5/16 Wrench
10mm Socket

Parts List / Hardware:

1 Upper Class Series Bumper
4 6-32 Nylon Lock Nuts
4 #10 Flat washers
4 2" Flange Brackets

Read and understand instructions before attempting installation

Step 1

Test fit the grille into the bumper opening. Open the hood on the vehicle. Remove a 10mm nut behind the grille in each corner (next to the headlight). Now remove the four 10mm bolts in the center of the grille. There are two plastic clips next to the headlight that clip into the core support (1). Pull the grille from the area around each headlight; remove the grille.



Step 2

With the upper grille removed; install the flange brackets, nuts and washers. Do not over-tighten the hardware. Re-install the factory grille onto the vehicle. ***Thank you for purchasing a T-Rex Billet Grille. 4/2/07***