



09-11 HYUNDAI GENESIS **Upper Class Bumper Mesh Grille**

TOOLS REQUIRED:

Socket and Ratchet Set
Flathead/Phillips Screwdrivers

PARTS LIST

(4) 1/2" L-Brackets
(4) 6/32" Nylon Lock Nuts
(1) Upper Class Mesh Grille



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquiries can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Factory Grille Removal

Open the hood. Remove the twelve plastic pop clips from the black plastic cover plate that is attached to the upper front of the engine compartment by pressing in the center of the pop clip with a pointy object (Fig 1) and pulling the pop clip out of the cover plate. There are also two 10/32" bolts that need to be removed from same plastic cover plate. Remove the plastic cover plate from the vehicle (Fig 2). Now remove two more plastic pop clips (one on each side) from the bumper cover top edge between the factory grille and the headlamps (Fig 3). Remove two phillips screws from the backside of the upper right/left corners of the factory grille, use a small ratcheting phillips screwdriver (Fig 4). There are two more phillips screws located on the back of the factory grille, they are located below the screws you just removed (Note these are a little difficult to reach). Now reach down behind the factory grille and locate the six plastic latches along the bottom and sides of the factory grille. Use your hands or a small flat screwdriver to unlatch them. Pull the factory grille forward and remove it from the vehicle.



Fig 1



Fig 2



Fig 3



Fig 4

Step 2 Upper Class Bumper Grille Installation

Now take the bumper mesh grille and insert it into the factory bumper opening (Fig 5). From the backside of the bumper cover locate the threaded studs that are welded onto the back side of the mesh grille and place the four L brackets on the threaded studs and latch them onto the lip in the factory bumper opening. Next take the four nylon lock nuts and place them on top of the L brackets and tighten (Fig 6). Reinstall the factory bumper cover. Installation complete.

