

T-REX

Billet Grilles

20799

**05-06 INFINITI
G-35 SEDAN**

20799

**05-06 INFINITI
G-35 SEDAN**

BILLET INSERT

Tools Required:

Phillip Screwdriver
Slotted Screwdriver

Hardware / Parts List:

1 Billet Insert (13 Bars)
4 Factory Fasteners

Read and understand instructions before attempting installation

Step 1

Remove the factory grille shell; use a small screwdriver to pull the center from each fastener. Four of the fasteners will be re-used; do not discard the fasteners. Next, lightly pull the top of the grille assembly forward. Use your fingers to depress the molded clips along the bottom of the grille. The grille can now be removed. If installing a bumper billet, install the bumper billet and then go to **Step 2** below.



Step 2

Center the billet insert into the opening. The lower mounting tabs align with the factory mounting holes. Slide these brackets into the mounting holes. Use the factory fasteners to secure the mounting brackets. The holes in the brackets may have excess powder-coat, so the factory fasteners may fit very tight. If needed, use a small round file or screwdriver to clean off some of the powder-coat. It may be necessary to slightly bend the upper brackets so they align correctly.



Step 3

The upper mounting tabs align to the factory mounting holes. It may be necessary to slightly bend the brackets so they align properly. Use the factory fasteners to secure the billet. Carefully check the clearance to the hood. If the billet is not aligned properly, remove the hardware and adjust the mounting tabs. ***Thank you for purchasing your T-Rex billet grille.***

T-Rex Truck Products Inc. 6/30/06