

10485
07-13 JEEP
WRANGLER



10485
07-13 JEEP
WRANGLER

07-13 JEEP WRANGLER
Spare Tire Carrier Hinge Kit

TOOLS REQUIRED:

Alcohol/Clean Rag

PARTS LIST:

1 T1 Series Spare Tire Carrier Hinge Kit - 2 Pc.

Step 1

Clean the area where the Spare Tire Carrier Hinge Kit will be installed with alcohol and a clean rag. Test fit the Spare Tire Carrier Hinge Kit. Remove the plastic backing on the adhesive on the back of the Spare Tire Carrier Hinge Kit.

Step 2

Position the Spare Tire Carrier Hinge Kit centered over the factory spare tire hinge as in the picture below. Press on the Spare Tire Carrier Hinge Kit to ensure the adhesive backing adheres to the factory spare tire hinge. Repeat process on the other hinge.

