

**10488**  
**07-13 JEEP**  
**WRANGLER**



**10488**  
**07-13 JEEP**  
**WRANGLER**

## **07-13 JEEP WRANGLER** **Climate Control Trim Plate**

**TOOLS REQUIRED:**

Alcohol/Clean Rag

**PARTS LIST:**

1 T1 Series Climate Control Trim Plate

**Step 1**

Clean the area where the Trim Plate will be installed with alcohol and a clean rag. Test fit the trim plate. Remove the plastic backing on the adhesive on the back of the Trim Plate.

**Step 2**

Position the Trim Plate on top of the factory center console as in the picture below. Press on the Trim Plate to ensure the adhesive backing adheres to the factory center console.

