

**21320
21320B
2011 KIA
OPTIMA**



**21320
21320B
2011 KIA
OPTIMA**

2011 KIA OPTIMA

Billet Grille Overlay

Install time: 30 Mins.

TOOLS REQUIRED:

Screwdriver
Plastic Prybar
10mm Socket Wrench

PARTS LIST:

(1) Billet Grille (4) 1' 1/4 6Head #8 Screws
(4) #8 U-Nuts
(4) 10/32 Fender Flatwashers

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

Step 1

- Remove 8 Clips on the Plastic Cover. (Fig. 1)
- Lift the Plastic Cover and remove.
- Remove 2 10mm Bolts towards the center of the Grille Shell. (Fig. 2)
- Towards the corners of the Grille shell, there will be hooks, With semi-force push the Grille Shell forward and pull up to unlatch the Grille Shell. (Fig. 3)
- Place a U-Nut through a Fender Flatwasher. (Repeat for Remaining Flatwashers). (Fig. 4)
- Place the Billet Grille over the Factory Grille. (Fig 5)
- Place the 1' 1/4 Screw through the Bracket on the Billet Grille. (Fig. 6)
- Pull the Factory Grille Shell outward so you have space (Need another Person to help) and insert the Fender Flatwasher with the U-Nut on the Threaded 1' 1/4 Screw (Fig. 7)
- Repeat for remaining Screws.
- Re-Assemble Hooks, Clips and Plastic Cover.

INSTALLATION COMPLETE

