

55644
06-08 LEXUS
GS350



55644
06-08 LEXUS
GS350

LEXUS GS350
UPPER CLASS SERIES MESH BUMPER

Tools Required:

Small Slotted Screwdriver
8mm Socket or Nut Driver
10mm Socket or Nut Driver

Part List:

1 Upper Class Bumper
4 6-32 Nylon Lock Nuts
4 #10 Flat washers

Read and understand instructions before attempting installation

Step 1

On the underside of the vehicle, remove the motor cover by removing the 10mm bolts [1].



Step 2

Locate the lower grille. Place grille into lower bumper opening. From back side of grille; place a washer and nylon lock nut on all four studs [2]. Center grille and tighten till snug

Step 3

Place the lower motor cover back on the vehicle.

*Thank you for purchasing a T-Rex Billet
Grille.9/18/07*

