





2013 LINCOLN MKT

Main Grille

Install time: 35 Mins.

TOOLS REQUIRED:

Flat Screwdriver Screwdriver 1/8 Drillbit+Drill Socket Wrench PARTS LIST: (1) Main Grille

(4) L-Brackets (8) 6/32 Washers 12) 6/32 Nylon Lock Nuts

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

Step 1 Factory Grille Install

• Remove 2 Bolts and Clips along the Top of the Plastic Cover. (Fig. 1)

• Lift up the Plastic Cover so you can fit your arm in. (Fig. 2)

• Place the Mesh Grille onto the Factory Grille Opening. (Fig. 3)

• Mark where the Top Threaded Studs on the Grille are and use a 1/8 Drillbit to Drill the Holes. (Fig. 4)

• Place a Washer and Nylon Lock Nut onto the Threaded Studs that you drilled Holes for. (Fig. 5)

• Place an L-Bracket and Nylon Lock Nut onto the Threaded Studs that you did not Drill Holes for. (Fig. 6)

INSTALLATION COMPLETE













