

**54768**  
**51768**

**2013 - 2015**

**NISSAN ALTIMA SEDAN**



**54768**  
**51768**

**2013 - 2015**

**NISSAN ALTIMA SEDAN**

## **2013 - 2015 NISSAN ALTIMA**

**Main Grille**  
Install time: 35 Mins.

### **TOOLS REQUIRED:**

Flat Screwdriver  
Screwdriver  
1/8 Drillbit+Drill  
Socket Wrench

### **PARTS LIST:**

(1) Grille  
(4) L-Brackets  
(4) Fender Flatwashers  
(8) 6/32 Nylon Lock Nuts

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.**

### **Step 1 Grille Installation**

- Remove 8 Clips across the top of the Plastic Cover and remove. (Fig. 1)
  - Remove 2 More Clips to Remove the Plastic. (Fig. 2)
  - Place the Mesh Grille over the Factory Grille and Mark where the Top Threaded Studs that are on the Mesh Grille are. (Fig. 3)
  - With a 1/8 Drillbit, Drill where you marked the Threaded Studs were. (Fig. 4)
  - Place back the Mesh Grille.
  - Place a Fender Flatwasher and Nylon Lock Nut along the top Threaded Studs on the Mesh Grille. (Fig. 5)
  - Place an L-Bracket along the Bottom Threaded Studs on the Mesh Grille so it Latches onto the Factory Grille. (Fig. 6)
- Repeat for remaining Studs.

**INSTALLATION COMPLETE**

