



2011-13 Polaris XP SERIES

Torch Series Grille

Install time: 25 Mins.

For off-road use only

TOOLS REQUIRED:

Screwdriver

PARTS LIST:

(1) Mesh Grille
(7) #8 Screws

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

- Remove 10 Screws (2 on Corner next to lights, 4 on Factory Grille, 2 on lower Bumper). (Fig. 1)
- Remove Front end Carefully to unplug the Wire connected to the Lights.
- Remove 7 Screws from around the Factory Grille and Remove. (Fig. 3)
- Place Grille Through the Grille Opening and insert the #8 Screws. (Fig. 4)



INSTALLATION COMPLETE

