

# 670060X

11-13 POLARIS  
XP SERIES



# 670060X

11-13 POLARIS  
XP SERIES

## 2011-13 Polaris XP SERIES

**Bumper Plate**  
Install time: 15 Mins.

**TOOLS REQUIRED:**

Screwdriver

**PARTS LIST:**

(1) Bumper Plate

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS  
BEFORE ATTEMPTING INSTALLATION.

- Remove 4 Screws on each corner. (Fig. 1)
- Remove the Plastic Cover. (Fig. 2)
- Place new Plate. (Fig. 3)
- Re-insert the Screws.

**INSTALLATION COMPLETE**

