

25458
25458B
2013 DODGE
RAM 1500



25458
25458B
2013 DODGE
RAM 1500

2013 DODGE RAM 1500

Billet Bumper
Install time: 20 Mins.

TOOLS REQUIRED:

3/16 Drillbit + Drill
Screwdriver

PARTS LIST:

(1) Billet Grille
(2) #8 Screws
(2) Flatnuts

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.**

Remove either the Splash Guard or the Plastic Cover along the Top of the Grille to reach behind the Bumper Opening.

- Place the Grille onto the Bumper Opening and Look at where the Brackets on the Grille is.
- With the 3/16 Drillbit, Drill through the Brackets. (Fig. 1)
- Place a #8 Screw through the Bracket and Place a Flatwasher Behind the Bumper Opening.
Repeat for remaining Bracket.

INSTALLATION COMPLETE

