

55947
10-13 TOYOTA
4RUNNER



55947
10-13 TOYOTA
4RUNNER

10-13 TOYOTA 4RUNNER

Upper Class Bumper Grille

TOOLS REQUIRED:

Socket & Ratchet Set
Flat/Phillips Screwdrivers

PARTS LIST

(4) 1/2" L-Brackets
(4) 6/32" Nylon Lock Nuts



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1

Open the hood. Use a small flat screwdriver to remove the 13 plastic pop clips on the radiator cover by pushing in on the center part of the pop clips (Fig 1). Remove the radiator cover. Take the mesh grille and insert it into the factory bumper opening. Reach down behind the mesh grille through the area where you removed the radiator cover and locate the threaded studs on the backside of the mesh grille. Place a 1/2" L-bracket on each stud making sure it latches around the plastic bars in the factory bumper opening and install a 6/32" nylon lock on top of the bracket, tighten (Fig3). Repeat this to all three mesh grilles. Reinstall the radiator cover. Installation complete.

