

**20938**  
**20938B**  
**2012 TOYOTA**  
**TACOMA**



**20938**  
**20938B**  
**2012 TOYOTA**  
**TACOMA**

## **2012 TOYOTA TACOMA**

### **Upper Class Billet Grille**

Install time: 35 Mins.

**TOOLS REQUIRED:**

3/16 Drillbit  
Screwdriver  
Dyegrinder

**PARTS LIST:**

(1) Billet Grille  
(7) #8 3/4 Screws  
(7) #8 Flatnuts

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.**

- Remove 2 Bolts and 1 Clip along the top of the Factory Grille. (Fig.1)
- Unclip 8 Clips along the Bottom of the Factory Grille to Remove.
- With a Dyegrinder, cut along the Factory Grille to remove Grille. (Fig. 2) (Do not remove the Black Tab along the bottom of the Factory Grille)
- Place Billet Grille onto the Factory Grille Shell. (Fig. 3)
- Securely have in place the Billet Grille. (make sure it fits properly) (Fig. 4)
- With a 3/16 Drillbit, Drill through the opening tabs on the Billet Grille. (Fig. 5)
- Insert the #8 Screws through the Holes you Drilled. (Fig. 6)
- Thread with provided Flatnuts. (Fig. 7)
- Place Grille Back onto the Truck. (Fig. 8)

### **Installation Complete**

