

**54939**  
**51939**  
**12-13 TOYOTA**  
**TACOMA**



**54939**  
**51939**  
**12-13 TOYOTA**  
**TACOMA**

## 12-13 TOYOTA TACOMA

**Hood Scoop**  
Install time: 10 Mins.

**TOOLS REQUIRED:**

Screwdriver  
1/8 Drillbit

**PARTS LIST:**

(1) Hood Scoop  
(2) 1" Screws

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS  
BEFORE ATTEMPTING INSTALLATION.**

- Place the Hood Scoop onto the Factory Hood Scoop. (Fig.1)
- Drill a 1/8 Hole through the 2 Holes on the Hood Scoop. (Fig. 2)
- Thread with Provided Screws. (Fig. 3)

**Installation Complete**

