

**54940**  
**51940**  
**12-13 TOYOTA**  
**TACOMA**



**54940**  
**51940**  
**12-13 TOYOTA**  
**TACOMA**

## **12-13 TOYOTA TACOMA**

### **Upper Class Mesh Overlay Grille**

Install time: 35 Mins.

**TOOLS REQUIRED:**

Socket Wrench

**PARTS LIST:**

(4) Mesh Grilles  
(10) L-Brackets  
(10) 6/32 Nylon Lock Nuts

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS  
BEFORE ATTEMPTING INSTALLATION.**

- Place the Grille on the Factory Grille. (Fig.1)  
From behind the Factory Grille, Insert an L-Bracket through the Threaded Studs so that the Mesh Grille will Latch onto the Factory Shell and Thread with provided Nylon Lock Nuts. (Fig. 2)  
Repeat for remaining Mesh Grilles.

**Installation Complete**

