

20896
05-10 TOYOTA
TACOMA



20896
05-10 TOYOTA
TACOMA

2 PC SIDE VENTS
BILLET INSERT

Tools Required:

Phillip Screw Driver
Drill – 1/16 Drill Bit

Hardware / Parts List:

2 - Billet Insert (9 bars)
2 - #8 X 1 Screws (# 6 Head)

Read and understand instructions before attempting installation

Step 1

Test fit the billets into the side openings. Each billet has a mounting tab welded to the rear of the billets. Mark the mounting hole to the openings. Remove the billets. Drill a 1/16" pilot hole for the mounting screws.

Step 2

Re-center each billet and secure the billets using the screws provided.

Thank you for purchasing your T-Rex billet grille. T-Rex Truck Products Inc. 1/17/05