

25961

10-12 TOYOTA
TUNDRA



25961

10-12 TOYOTA
TUNDRA

10-12 TOYOTA TUNDRA Bumper Billet Grille Insert 3 Pc.

TOOLS REQUIRED

8mm Socket and Ratchet
Phillips Screwdriver

PARTS LIST

(4) 2" Screws
(4) 3" Custom Tundra Bumper Brackets
(4) 6/32 Nylon Lock Nuts
(3) Billet Grilles

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1

Take one of the billet grilles and insert it into the appropriate bumper opening, the tabs that are welded onto the backside of the billet grilles should be near the bottom (Fig 1).

Step 2

Now take the 2" screws and insert them through the front of the grille and through the tabs that are welded onto the back of the grilles (Fig 2). From the backside of the bumper slide the 3" custom brackets over the screws, the bracket side with the hole in it will be on the bottom, place a 6/32" nylon lock nut on top of the bracket and tighten. The center grille has two screws, nuts and brackets. The side grilles each have one screw, nut and bracket. Installation complete.



Fig 1



Fig 2