

**54961**  
**10-12 TOYOTA**  
**TUNDRA**



**54961**  
**10-12 TOYOTA**  
**TUNDRA**

## **10-12 TOYOTA TUNDRA**

### **Upper Class Mesh Grille 1 Pc.**

#### **TOOLS REQUIRED**

8mm Socket and Ratchet

#### **PARTS LIST**

(8) 1/2" L Brackets

(8) 6/32" Nylon Lock nuts

(1) Upper Class Mesh Grille

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at [tech@trexbillet.com](mailto:tech@trexbillet.com) to verify fitment or assist with tech questions. All other inquiries can be directed to [info@trexbillet.com](mailto:info@trexbillet.com). In the event you do not have internet access please call 1-800-287-5900.

#### **Step 1 Install**

Open the vehicles hood, take the mesh grille and insert into the factory grill. On the backside of the factory grill locate the threaded studs from the mesh grille. Install the eight 1/2" L brackets onto the threaded studs, the L brackets will wrap around the black plastic slats of the factory grille. Install the eight 6/32" nylon lock nuts on top of the brackets and tighten. (Fig 1) Installation complete.

